

## IRON MAID INSTALLATION INSTRUCTIONS

### E-Z-GO TXT

**Step 1:** Assemble cleaner to bracket with 4 screws provided, torque to 15 inch-pounds.

**Step 2:** At the bagwell floor level, measure 6 ½" from the front of the bagwell and make a mark.

**Step 3:** Measure 9 5/8" up from the mark made in step 2 and mark the location for the first hole.

**Step 4:** Drill the first hole with ¼" drill bit, install the first mount bolt, nut and washer, tighten to 35 inch-pounds.

**Step 5:** Rotate the assembly toward the front of the car until the front edge of the bracket touches the bagwell.

**Step 6:** Using the bracket as a guide, drill two ¼" holes in the forward positions (the rear upper position is not used).

**Step 7:** Install second and third mounting bolt, tighten to 35 inch-pounds.

Step 1



Step 2



Step 3



Step 5



Rubber "tongues" minimize splashing



Side window shows fluid level

[www.clubpro.com](http://www.clubpro.com)

Please call us with any questions pertaining to these instructions or any repair maintenance of the product  
1-800-467-2844

