

## QUICKSAND 2 BOTTLE MOUNTING FOR YAMAHA DRIVE / DRIVE 2



### Step 1



Align bracket to factory holes in sweater basket strut. Attach with M8 bolts with washer and nut on back side.

### Step 2



Align peg on plastic bottle holder with lower hole in bracket. Place M6 washer on M6 bolt and insert in hole in plastic bottle holder so flat washer is in contact with the plastic bottle holder. Install M6 locknut on back side of bracket.



### Step 3



Place bottle in holder.

### SUPPLIED HARDWARE

1. Single Mount Bracket
2. M8 x 40 Bolt (x2)
3. M8 Washer (x2)
4. M8 Locknut (x2)
5. M6 x 15 Bolt (x2)
6. M6 Washer (x2)
7. M6 Locknut (x2)

