

## CLUB CAR RAIL ENCLOSURE INSTALLATION

### Step 1



Front canopy bolt with 3 inches of rail forward of the bolt.

### Step 2



Rear grab handle bolt with ½ spacer between rail and handle.

Hold the 43-inch-long rail up to the cart with 3 inches extending past the forward canopy mounting bolt. Mark the location of this bolt on the rail. While holding the rail in place mark the location of the rear canopy grab handle bolt on the rail. Drill a ¼ hole in rail at both marked locations. Install the rail on the cart using the supplied M6x60 bolt with a flat washer under the head from the inside of the cart. Use a ½ inch spacer between the rail and the cart. Secure with an M6 nylock nut.

### Step 3



Center the 18-inch rail on the inside of the “tab” on the inside of the canopy and mark holes for drilling approximately 2 inches from each end. Drill ¼ holes at each marked location. Transfer drill holes from the rail into the tab. Secure the rail with the bead facing inside the cart with the supplied M6x20 bolts with flat washers under the head and the M6 nylock nuts.

### Step 4



Replace the factory windshield extrusions with the new supplied parts, secure with factory hardware.

### Step 5



Secure the front panels to the new windshield extrusions by pressing the rubber channel onto the tab on the backside of the extrusion.

Wrap the Velcro straps around the front uprights and secure back onto the panel. Slide the side and rear panels into the rails and zipper panels to each other.

**CLUB CAR RAIL ENCLOSURE INSTALLATION****Step 6**

Attach the adhesive snap onto the snap on the front panel. Use the panel to approximate the location the snap will attach to the rocker panel. Clean the rocker panel and allow to dry. Apply the 3M adhesive primer to this area and allow to dry. With the snap still attached to panel expose the adhesive backing and set in place using the panel as a locating guide. Keep pressure on the snap for 60 seconds. Allow the snap adhesive to set for 24 hrs. without disturbing.

**SUPPLIED HARDWARE**

M6x60 SS bolts x4  
M6x20 SS bolts x2  
M6 flat washers x6  
M6 nylock nuts x6  
½ inch spacers x4  
Adhesive snaps x2  
Primer stick 1pc  
43-inch rail x2  
18-inch rail 1pc  
Windshield extrusion L/R

