

DIVOT STATION MOUNTING INSTRUCTIONS - YAMAHA



Step 1



Attach sand bottle holders to the right and left side of the Iron Maid bracket using the supplied M6x15 bolts with a washer under the head and nylock nuts.

Step 2



Attach the Iron Maid to the bracket using the supplied self-tapping screws.

Step 3



Secure the bracket to the sweater basket support strut. Insert the supplied M8x40 bolt into the bracket and through the lower factory hole on the sweater basket support strut. Secure on the back side of the strut with the M8 washer and M8 lock nut.

Step 4



Final assembly.

www.clubpro.com

800.467.2844 info@clubpro.com

AUGUSTA, GA | DEER PARK, NY | DETROIT, MI | LOUISVILLE, KY | SANTIAGO D.R.

