

The "People Mover" Cart Enclosure Installation Instructions

Encased steel frame permanently attaches to cart, with two small C-clamps and set screws.



Allen wrench provided to torque down C-clamps used to attached steel strut of the cover to front frame of cart. C-clamp faces out. Set screws torque into steel strut of the cover, NOT the cart.



Assembles in seconds, NO DRILLING, NO VELCRO.

Cover disappears into storage valence.

"Jam - Cleat" bungee hooks provide snug fit to cart bottom.

Transparent back panel offers protection as well as visibility; easy access to rear seats; disappears quickly into storage valence