

RANGER PROTECTOR INSTRUCTIONS ALL MODELS

Thank you for purchasing the “RANGER” golf cart protector.
To ensure the proper care & use of this product, please read
the following instructions:

PLEASE READ THE PRODUCT DISCLAIMER AND
LIMITATION OF LIABILITY, THAT IS ATTACHED TO
THE PRODUCT BEFORE USING.

1. Remove paper from the windshield before using.
2. As depicted above, attach shock cords through the two positions, 1 and 2, where grommets are placed at the bottom of the Ranger. Allow the rear position to rest under the rear leaf springs of the golf cart. It is very important that both shock cords are always in place to ensure the tension to the mesh around the golf cart.
3. Insert steel strut from A to B using the steel position A to B in the proper direction. Section A has a Velcro opening, allowing the steel strut to be inserted and sealed by closing the Velcro once the steel has been inserted.
4. Be sure that while in use, the zipper is in the down position ensuring a tight fit to the golf cart.



Please call us with any questions pertaining to these
instructions, repair maintenance of this product at
1-800-467-2844

